








*



DE- passend wählen
GB- choose suitable
FR- sélectionnez appropriée
ES- escoger adecuado
RO- selectati adecvat



DE- * Spannungsfrei demontieren

GB- * Volt-free dismantling

FR- * Démontage hors tension électrique

ES- * Desmontar sin voltaje

RO- * a nu se demonta cât timp se află sub tensiune electrică